GRUNDIG

WORLD RECEIVER

MINI WORLDBAND 100 PE

AUTHORIZED GRUNDIG STORE

agsradio.com

Toll Free US & Canada 1 866 282 4801

AUTHORIZED GRUNDIG STORE

As a proud representative of Grundig's radio products, the Authorized Grundig Store is pleased to offer this support manual, as delivered OEM Grundig AG with Mini Worldband 100PE radio. It is available on the world wide web through our website in Postscript Document Format (pdf) and may be downloaded free of charge, viewable with the recommended utility Adobe Acrobat Reader 4.0 or later.

Toll Free US & Canada 1 866 282 4801

agsradio.com

Created by

SHINING BLUE MOON

Toronto Canada robertson@shiningbluemoon.com

© Copyright 2003 Authorized Grundig Store

NEED HELP?
CALL OUR HOTLINE

If, after reading this owner's manual, you need help learning to operate your MINI WORLDBAND 100PE, call GRUNDIG toll free, Monday through Friday, 8.30 am to 4.30 pm, PST at:

1-800-872-2228 from the U.S.
1-800-637-1648 from Canada

OWNER'S RECORD

This model is the GRUNDIG MINI WORLDBAND 100 PROFESSIONAL EDITION (PE), an AM/FM-Stereo with Earphones and 6 Shortwave bands.

The serial number is located on the sticker inside the battery compartment. Refer to this number whenever you call GRUNDIG regarding this product.

CONTROL LOCATIONS



1. Telescopic Antenna for FM/SW
2. Band Selector
3. Frequency Tuning Dial Scale Display
4. Tuning Dial
5. Volume and Power On/Off Switch
6. Earphone Jack
7. Battery Compartment (on back)
8. LED Tuning Indicator
9. Removable Belt Clip (on back)

USING THE RADIO

Install 2 AA size batteries (not included) into the Battery Compartment at the rear of the radio (See Control Locations item #7 previous page).

Turn ON the radio (#5) and adjust the Volume (#5) to the desired listening level.

Select the required frequency range with the Band Selector (#2).

Select the desired radio station by turning the Tuning Dial (#4). When a strong signal is obtained the Tuning LED indicator will light (#8).

FOR AM the set is provided with a built in antenna which may be directed by turning the entire set.

FOR FM/SW the Telescopic Antenna (#1) must be extended completely for best reception.

FOR FM-STEREO use the Earphones (included) in the Earphone Jack (#6).

SPECIFICATIONS

1. Frequency Range

FM:	88 - 108 MHz
AM:	525 - 1710 KHz
SW1 (49m):	5.80 - 6.40 MHz
SW2 (41m):	6.90 - 7.50 MHz
SW3 (31m):	9.40 - 10.00 MHz
SW4 (25m):	11.65 - 12.15 MHz
SW5 (19m):	15.00 - 15.65 MHz
SW6 (16m):	17.50 - 18.14 MHz

2. Power Output: 100mw

3. Speaker: 0.45mm, 0.25mw, 4ohm

4. Power Supply: 2 x AA batteries (not included)
DC 3V

5. Earphone: 8-32ohm, 3.5mm dia. plug

6. Dimensions: 4 1/2”H x 2 5/8”W x 13/16”D